

ABTW_0070 - B787 ULDs and Baggage Answer Key

B787 ULDs and Baggage Review

Container curtains and door straps must be closed whenever ULDs are being transported, whether they are loaded or empty.

- ☒ True
- ☐ False

B787 ULDs and Baggage Review

"Tare weight" is:

- ☐ The maximum payload of a ULD.
- ☒ The weight of an empty ULD.
- ☐ The combined weight of a ULD and its contents.
- ☐ The combined weight of all ULDs loaded onto the aircraft.

B787 ULDs and Baggage Review

WestJet will use primarily _____ containers in B787 service

- ☐ LD-2 (DPE)
- ☒ LD-3 (AKE)
- ☐ LD-6 (ALF)
- ☐ LD-8 (DQF)



ABTW_0070 - B787 ULDs and Baggage
Answer Key

B787 ULDs and Baggage Review

ULDs are considered part of the aircraft's structure as soon as they are loaded onto an aircraft. Loading damaged ULDs onto the aircraft is essentially the same thing as damage to the aircraft itself.

- ☒ True
- ☐ False

B787 ULDs and Baggage Review

Select all of the **true** statements below about live animals.

- ☐ Only cargo AVIs are accepted for transport on WestJet's B787.
- ☐ Load Control will advise where AVIs must be loaded.
- ☐ AVIs in kennels must be loaded into the bulk hold.
- ☒ AVIs will not be accepted for carriage in the holds of the B787 at this time.

B787 ULDs and Baggage Review

Motorized wheelchairs travelling as checked baggage are:

- ☐ Secured in the bulk hold.
- ☐ Secured onto pallets by the cargo warehouse and loaded as per Load Control's direction.
- ☐ Accepted for carriage in the main cabin only.
- ☒ Secured into ULDs and loaded as per Load Control's direction.

ABTW_0070 - B787 ULDs and Baggage
Answer Key

B787 ULDs and Baggage Review

WestJet's delivery standard for priority baggage is:

- ☒ Priority baggage must be the first local baggage to appear on the carousel for guest pick-up.
- ☐ Priority baggage must be offloaded before any other commodity.
- ☐ Priority baggage is loaded last.
- ☐ Priority baggage must be transported to the carousel without any other commodities.

B787 ULDs and Baggage Review

When possible, deliver the baggage from the Priority containers immediately after it has been offloaded from the aircraft.

- ☒ True
- ☐ False